
#### McKEON DOOR COMPANY

# **Fire Door Systems**

### A Guide to Code Compliance





www.McKeonDoor.com

# **Fire Door Systems**

A Guide to Code Compliance



#### **McKeon Door Company**

44 Sawgrass Drive • Bellport, NY 11713 Phone: 800-266-9392 • Fax: 631-803-3030 www.McKeonDoor.com • E-Mail: info@mckeondoor.com

### Contents

#### **APPLICATIONS** (Opening Protectives)

#### **Elevator Separation**

Elevator Lobby
Elevator Smoke & Draft 10
Exit Access Separation
Horizontal Exit
Exit Passageway
Pedestrian Walkways & Tunnels
Vertical Opening Separation
Fundamental Guidelines
Non-Egress Stairs
Shaft Enclosures – Escalator
(Vertical) Exit Enclosures

#### **Occupancy Separation**

Fundamental Guidelines	52
Mixed Occupancy – Accessory Use	54
Mixed Occupancy Use - Non-Separated vs Separated	58

#### Area Separation

Allowable Area	. 66
Corridor Separation	

Corridor Separation – Healthcare.	. 72
Smoke Compartmentation	

Smoke Compartments – Healthcare	. 80
Smoke Barriers – Healthcare	. 84

#### APPENDIX

#### Definitions

Fire Walls
Fire Barriers
Fire Partitions
Smoke Barriers
Smoke Partitions
Resources
International Building Code, 200995
NFPA 101 Life Safety Code, 200696
ICC Evaluation Service Report

#### 4th Edition - September 2011

Copyright © 2011 by McKeon Rolling Steel Door Co., Inc. All rights reserved. No part of this book may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of the publisher. For more information contact info@mckeondoor.com.

# Introduction

THE INTERNATIONAL BUILDING CODE has been widely accepted in the United States and is recognized as a uniform code addressing the design and installation of building systems with performance-based requirements. The current International Building Code has been developed over the last decade through the extensive work and efforts of code enforcement personnel organized at both local and national levels under the direction of the International Code Council. A vital part of the development of the building code is the involvement of industry and nationally recognized organizations with interests in building product development and the protection of public health, safety and welfare.

THE McKEON DOOR COMPANY develops and manufactures numerous fire and smoke rated assemblies that function as wide-span opening protectives. These building products enter the marketplace specifically to assist design professionals and code enforcement personnel in satisfying open design without compromising fire and life safety requirements. This document is formatted to present the building code as it pertains to the use of opening protectives; first, recite performance-based requirements in laymen's terms for common-sense understanding, second, include specific technical code language as required, and third, illustrate product case studies presented as design solutions to frequently approached complex code application challenges. The building code interpretations found herein represent the opinion and experience of the preparer, intended only to assist the reader in recognizing and understanding the potential use and application of McKeon fire and smoke rated opening protective assembly products.

# **Elevator Separation**





## **Elevator Lobby**

Section 708.14.1

The elevator lobby is designed to isolate the fire-rated elevator shaft enclosure and its doors from the remainder of the floor on which it opens. The building code does not require this separation until the elevator shaft enclosure connects more than three stories (708.14.1).

#### Fire & Life Safety Concerns

Elevator shafts commonly represent the greater quantity of inter-connecting vertical shafts in multi-story buildings. These shafts become conduits for heat, smoke and other toxins from the fire floor(s) to additional floors.

#### **Code Requirements**

708.14.1 Elevator lobby. An elevator lobby shall be provided at each floor where a elevator shaft enclosure connects more than three stories. The lobby enclosure shall separate the elevator shaft enclosure doors from each floor by fire partitions. In addition. . .doors protecting openings in the elevator lobby enclosure walls shall comply with Section 715.4.3 as required for corridor walls. . .

Exception #1 – Not required at the street floor when the entire floor is sprinklered. Exception #2 – Elevators that are not required to be located in a shaft in accor-

dance with Section 708.2.

Exception #3 – Where additional doors are provided at the hoistway opening complying with UL 1784. In this case a swing door may be placed at the point of access to the car, however it is important to note that each opening must be protected individually.

Exception #4 – Lobbies are not required as long as the entire building is sprinklered. However, this exception does not apply to Group I-2, I-3 and High-Rise.

Exception #5 – Smoke partitions (non-rated) can used in lieu of fire partitions to create the lobby as long as the entire building is sprinklered.

Exception #6 – Not required when the hoistway is pressurized.

Exception #7 – Not required in open parking garages in accordance with Section 406.3.

#### **Design Solutions**

The design of an elevator lobby is typically the least intrusive and least expensive option in multi-story buildings for elevator shaft protection. The multiple-option McKeon door assemblies easily accommodate radius applications, wide-span openings and egress. The use of the McKeon door assembly eliminates the need for cased openings or jambs and allows for recessed installation into walls and ceilings providing clear open appearance.

Note: The building code now requires in buildings four stories or more at least one elevator dedicated as a means of egress for the disabled during an emergency or fire (Section 1007.2.1; 1007.4). In order to access the elevator the opening protective, whether it be at the point of access or part of the lobby, must be an approved self and automatic closing conforming exit assembly (Section 1008.1). This can only be achieved with a side acting accordion fire door approved in a means of egress or a conventional swing door.


#### • Case Study 1: Vertical Acting with Complying Swing Egress Door(s)



This first case study features a vertical rolling steel door technology that incorporates a conventional egress door. Since head room was very plentiful and side stacking room was not available, this vertical acting assembly was chosen to meet the fire & life safety requirements without compromising design.




• Case Study 2: Side Acting Accordion with Power-assisted Egress




Unlike the previous case study, there is no headroom and side stacking space is limited. The McKeon bi-parting accordion fire door technology stepped up to meet the demand of hi-end design without compromising specific code requirements including conforming side acting accordion fire door egress acceptance.

WWW------







 Case Study 3: Side Acting Accordion with Complying Swing Egress Door & Vertical Acting with Complying Swing Egress Door(s)



Case Study 4: Side Acting Accordion with Power-assisted Egress



The side acting accordion technology will accommodate custom radius applications as well as serve as the primary means of egress from the space.



#### **Inquiry Discussion & Questions**

The charging language, as well as any one of the above listed seven exceptions will allow the designer to comply with the elevator separation requirements. The seven options are a combined total of both active and passive systems. For example sprinkler systems or shaft pressurization systems are active systems that either move water or air as discussed in Exceptions #1 and #6. These are considered active systems because when there is an alarm these mechanical devices go into action and actually put the fire out with water or move enough air in the elevator hoistway shaft to eliminate smoke from entering.

Passive systems are best illustrated by Exceptions #3 and #4. When the building goes into alarm enclosures are formed either around the elevator space or at the point of access to the car in order to stop smoke from spreading. Similar to fixed walls these enclosures are considered passive because they are non-mechanical and do nothing to extinguish or eliminate fire and smoke, the enclosures simply block it from passage. Most often passive and active systems compliment each other as prescribed in Exception #5.

Along with fire and life safety concerns, the design professional must consider two additional critical areas – cost and appearance. The optimum circumstance is to have a non-obtrusive ambiance at minimal cost, regardless of the diverse individuality of each building design. Listed below are fundamental principles, as associated with several of the exceptions, combined with pertinent questions to address possible solutions:

• Exception #3 allows protection at the point of access to the car without creating a lobby as long as the provisions of UL 1784 are met. The opening protective at the point of access to the elevator car is not required to be fire rated because the elevator car doors are fire rated. However, elevator car doors are not smoke rated, therefore, an opening protective at the point of access may or may not work in conjunction with the rated elevator car door to meet both fire and smoke requirements. First, let's examine two potential technologies as solutions:

Individual side-hinged swing doors – From the cost perspective this is certainly a less expensive option. From the appearance and functionality of the space point of view this option is very difficult. The swing door must be held open on an electro-magnetic catch that is mounted adjacent the hinged side of the door. This requires large areas of wall space to accommodate the width of the swing door which must be equal to the width of the elevator car door opening located next to the car opening. This is nearly impossible to accomplish with multiple elevator door openings and elevator control buttons.

Also, the following language in the code presents challenges in minimum width corridors – rated or non-rated:

 (IBC) 1005.2 Door encroachment. Doors opening into the path of egress travel shall not reduce the required width to less than one-half during the course of swing. When fully open, the door shall not project more than 7 inches (178 mm) into the required width.

In order for the elevator car opening to accommodate a side-hinged swinging door assembly the jamb must be framed and cased as well as electrical rough-in and hardware finish for the hold-open device installed. In multiple elevator car door applications it is questionable as to any significant cost savings. Obviously appearance is very undesirable whether a single or multiple applications.

*Vertical Rolling Barriers* – Vertical rolling steel doors without egress doors or films that are magnetically attached to the elevator frames are not approved by the building code as conforming exit doors in a means of egress.

Until recent acceptance of Accessibility provisions the elevator car was not a component of the means of egress system. Therefore an elevator car was not considered an occupied space in the building. This reasoning was based on the premise that when a building goes into fire alarm the elevators would lock-out (not be accessible from any other floor) and immediately return to the ground floor thereby disallowing any building occupant to ingress or egress the elevator car until it was safely out of danger. Should the elevator malfunction and stop on an intermediate floor it would then be necessary to allow the elevator car occupant(s) to choose whether or not to exit the car. Any protection at the point of access to the elevator car at this juncture must comply with the code:

 (IBC) 3002.6 Prohibited doors. Doors, other than the hoistway doors and the elevator car door, shall be prohibited at the point of access to an elevator car unless such doors are readily openable from the car side without a key, tool, special knowledge or effort.

Some jurisdictions allow the roll-down films to be used in this application because they incorporate side-jamb magnets so that when the film is pushed from the car side it will detach from the door frame jambs and allow egress. It is assumed this egress function can take place "without a key, tool, special knowledge or effort."

However, the introduction of the International Building Code brought with it new Accessibility provisions in Section 1007 specifically placing elevators as a component of the Exit and Exit Access portions of the Means of Egress system in buildings four stories or more in height. Therefore anything placed at the point of access to an elevator car considered part of an accessible means of egress must conform to the requirements of a required exit assembly. These new Accessibility provisions require ingress into the elevator as well as egress out of the elevator car. Roll-down films that do not provide conforming egress are not in compliance.

From a cost perspective, particularly in multiple elevator car applications, it is very expensive to separate individual openings. Overall, a full lobby created with concealed wide span opening protectives is less expensive and does not compromise the design of the space.

 Exception #4 The charging language in Section 708.14.1 exempts structures three stories or less from having elevator separation provisions. It specifically requires all other structures four stories or more to include lobbies. The reason for this charging language is that the elevator lobby provisions are calculated to defend-in-place building occupants until rescue help arrives.

Nevertheless, this exception considers an entire sprinklered floor equal in task to an elevator lobby area of refuge. This exception is does not apply to hospitals, prisons and hi-rise buildings. With regard to hospitals – I-2 occupancies – Sections 407.4.3 and 712.9 require protection at the lobby area, despite the number of stories served. Ironically, the previous Exception #3 overrides all of these considerations when applied.

- Exception #5 provides an alternate means of construction of the walls creating an elevator lobby. Even though this provision allows non-rated construction with smoke partitions the opening protectives must remain UL1784 listed. The passage of smoke is still an issue and rated opening protectives are still required.
- Exception #6 is a very expensive alternative when the building exceeds 5 or 6 stories. The greater the cubic footage of space to pressurize the greater the cost in mechanical equipment to do the job. Most designers have suggested this alternative is equitable in 5- and 6-story buildings as compared with pas-

sive redundancy. However all agree that beyond this 5th or 6th level passive redundant lobbies are the least expensive alternative in multi-story buildings to satisfy elevator separation requirements.

The following questions regarding hi-rise buildings may be helpful:

- Most elevator core areas exceed 10 feet in width. When creating an elevator lobby separation do you find it difficult to maintain clear open appearance using traditional gypsum board walls and swing doors, due to head and jamb requirements, with a maximum 8 foot width?
- Would you like to delete the build-outs created to accommodate swing doors on magnetic hold-open devices at the elevator lobby?
- Have you considered the additional cost and the appearance of custom swing doors on hold-up devices in protecting the elevator lobby?
- In multiple elevator applications have you considered the increased cost of designing individual elevator separation over a simple lobby approach?
- What is the cost difference between pressurization and a simple lobby?
- Are you aware there are significant problems certifying pressurization systems?
- Are you required to have at least one elevator as an accessible means of egress? If so, do you have conforming exit assemblies at the point of access to the elevator car?
- How do you distinguish separation between standard elevators and conforming accessibility elevators?

#### Notes:

### Elevator Smoke & Draft

Section 715.4.3.1

Elevator car doors are typically fire-rated but cannot comply with smoke and draft requirements. Smoke & draft rated assemblies eliminate the passage of smoke and are usually located at the point of access to an elevator car as an alternative to the elevator lobby.

#### Fire & Life Safety Concerns

Elevator shafts commonly represent the greater quantity of inter-connecting vertical shafts in multi-story buildings. These shafts become conduits for heat, smoke and other toxins from the fire floor(s) to additional floors. In buildings that connect more than three stories the conventional elevator lobby is presumed to stop fire and smoke with no requirement for the elevator car doors to be smoke and draft rated. However, when eliminating the lobby there is concern that smoke can penetrate quickly at the point of access to the shaft. Therefore, all fire-rated assemblies used at the point of access must maintain a smoke and draft rating. *(UL 1784)* 

#### **Code Requirements**

In the legacy codes elevator protection requirements were driven by rated corridor provisions. In other words, whenever an elevator opened to a rated corridor the threat of creating a "dirty" (smoke & heat filled) corridor was mitigated by providing protection at the point of access in lo-rise construction and a conforming lobby in hi-rise construction.


Currently in the IBC protection at the elevator is driven only by "where an elevator shaft connects more than three stories" (708.14.1). At first glance one would think a four story building less than 75 feet in height (lo-rise by definition) would require elevator protection. However, Exception #4, 708.14.1 allows buildings that are sprinklered to be exempt unless it is a High-Rise or a Group I-2 or I-3 occupancy.

Therefore, this application becomes a code requirement in rare cases where a building connects more than 3 stories, is less than 75 feet in height and is not sprinklered.

Please note: All assemblies located at the point of access to an elevator car must be readily openable from the car side without a key, tool, special knowledge or effort. *(3002.6)* 


#### **Design Solutions**

#### • Case Study 1: Side Acting Accordion with Ppower-assisted Egress




Due to the several configuration options of the McKeon door assemblies multiple or single elevator openings can easily be protected. Egress can be placed at each elevator car door opening to accommodate conforming exit requirements.







• **Case Study 2:** Vertical Acting with Complying Swing Egress Door(s)








• **Case Study 3:** Vertical Coiling with Complying Swing Egress Door(s)









• Case Study 4: Side Acting Accordion with Power-assisted Egress




WWW------

The single track 3-hour rated accordion will accommodate 18" radius to custom curves. Along with complying egress, McKeon resolved a very difficult challenge without life safety or design compromise.









#### **Inquiry Discussion & Questions**

In hi-rise buildings this application is allowed under Section 708.14.1, Exception #3. Please consult the Inquiry Discussion & Question section of the Elevator Lobby case study.

Notes:

# **Exit Access Separation**





## Horizontal Exit

Section 1025

Horizontal exits are designed to move building occupants on a floor from any point in the exit access system to a fire and smoke protected area.

#### Fire & Life Safety Concerns

Fundamentally the horizontal exit differs from the typical code defined exit. The horizontal exit is calculated to "defend in place" by creating an area of safe refuge for building occupants within the confines of the building structure. All other exits are designed to exit occupants out of and away from the building.

#### **Code Requirements**

Because building occupants are not being removed from the building when utilizing the horizontal exit, specific precautionary requirements are based upon the following fundamental principles:

**Principle #1** – A 2-hour fire wall or fire barrier must be used to separate safe refuge areas connected with a horizontal exit (Section 1025.2). The determination between the use of a fire wall or fire barrier is the function of the wall as it relates to other code requirements.

**Principle #2** – The opening within the horizontal exit must be protected with a self-closing or automatic closing fire door when activated by a smoke detector. The fire rating of the door must be a minimum of 90 minutes. *(Sections 1025.2 & 1025.3)* 

**Principle #3** – A horizontal exit cannot serve as the only exit from the fire area. In cases where two or more exits are required, not more than one-half shall be horizontal exits (1025.1). In order to minimize this requirement the following criteria must be met:

Exception #1: In an I-2 (hospital) occupancy horizontal exits can comprise twothirds of the required exits. (Section 1025.1, Exception #1)

Exception #2: In an I-3 (prison) occupancy horizontal exits can be the only and primary means of egress from the space. (Section 1025.1, Exception #2)

**Principle #4** – The capacity of the refuge areas separated by a horizontal exit are calculated based upon the following:

- 1. The refuge area shall be occupied by the same tenant. (Section 1025.4)
- 2. The refuge area must be large enough to accommodate the original occupant load plus the occupant load anticipated from the adjoining fire area. *(Section 1025.4)*
- 3. The only exceptions to these rules are in I-2 and I-3 occupancies. (1025.4, Exceptions #1 through #3)

#### **Design Solutions**

Case Study 1: Side Acting Accordion with Complying Swing Egress Door



In this particular case study the intent is to add a 9,700 square foot critical care suite on an existing I-2 (hospital). However other code requirements come into play affecting the design dramatically:


- First, suites of sleeping rooms cannot exceed 5000 square feet and in this case a 9,700 square foot suite is being added. (1014.2.2.2)
- Second, there must be two exits from each suite. (1014.2.2.2)
- Third, the travel distance between any point in a suite of sleeping rooms and an exit access exit door shall not exceed 100 feet. (1014.2.2.2)

By utilizing the horizontal exit concept, the following will preserve the original design intent and provide code compliance:

- Separate the intended 9,700 square foot space into two suites, each less than 5,000 square feet.
- Provide a 2-hour fire barrier wall as the separation. (Section 1022.2)
- Provide a horizontal exit in the separation as one of two required exits from each space. (Sections 1014.2.3.1; 1014.2.3.2; 1014.2.3.3)
- Provide a 90-minute opening protective. (Table 715.4)







#### **EXIT ACCESS SEPARATION**


• Case Study 2: Vertical Coiling with Complying Swing Egress Door(s)

0	0
	$\square$

McKeon offers a particularly unique resolve for this airport design. Because the concourse is located above ground level and in a TSA secure area, it is not possible to provide exiting to the exterior. Also, there is not room for build-outs or pocket spaces, therefore unique to the T2500 technology a 90-minute opening protective is provided with no side room and as little as 26 inches of head-room with conforming dual egress doors. In essence each side of a long fire and smoke rated concourse forms one of two areas of refuge.







#### **EXIT ACCESS SEPARATION**

#### **Inquiry Discussion and Questions**

It has been said by many that the horizontal exit is probably one of the least understood and least utilized concepts of the building code. The following questions may be helpful in promoting awareness:

- Do you encounter travel distance problems in areas of the code other than the standard travel distance tables? (this case study for example)
- When designing a horizontal exit, does the 2-hour wall inhibit the openness of the space under consideration?
- In health care or prison design may I show you how a required smoke barrier can also serve as a horizontal exit?

Notes:

# Exit Passageway

Section 1023

An exit passageway provides the designer with an acceptable way of connecting a required exit stair to the exit discharge. Because the code requires an exit stair to open directly into an exit discharge to the exterior of the building, this provision will allow the stair to terminate at convenient locations away from the exterior walls. Also, the exit passageway can extend the path of travel when travel distances in the exit access system have been exceeded.

#### Fire & Life Safety Concerns

Extending the path of egress beyond the terminated travel distance or beyond the exit vestibule increases the potential for building occupants to be exposed to fire, smoke or hot and toxic gases. For these reasons exit passageways are designed with more strict provisions.


#### **Code Requirements**

- 1. An exit passageway shall not be used for any purpose other than as a means of egress. (1023.1)
- 2. Exit passageway enclosures shall have walls, floors and ceilings of not less than 1 hour ... and be constructed as fire barriers. (1023.3)
- 3. Elevators shall not open into an exit passageway. (1023.5)
- 4. Opening protectives shall comply with Section 715 ... and shall be limited to those necessary for exit access to the exit passageway from normally occupied spaces and for egress from the exit passageway. (1023.5)

#### **EXIT ACCESS SEPARATION**

#### **Design Solution**


#### • Case Study: Side Acting with Complying Swing Egress Door(s)



In this case study the required exit stair from the floors above terminated several feet from the exterior of the building. Because of the listed door label the McKeon opening protective left the space open between the stair and the exit discharge to the outside.







#### **Inquiry Discussion and Questions**

Because exit passageways are constructed under strict opening provisions, designs rarely incorporate them unless there is no other choice. With the use of the McKeon wide-span opening protectives, openings are not limited in size and little or no design compromise is noticed by building occupants. The following questions can be helpful in assisting the design professional to recognize new options:

- Have you ever desired to terminate a required exit enclosure on the interior of the building rather than at the exterior exit?
- Do you find challenges in connecting an exit enclosure with the exit to the exterior of the building?
- Did you know that solving a travel distance problem by providing an exit passageway can open your design rather than close it down?

## Pedestrian Walkways & Tunnels

Section 3104

Walkways and tunnels are designed to provide connection between buildings. They can be located at, above or below grade level and are used as a means of travel by persons.

#### Fire & Life Safety Concerns

Buildings located across lot lines from each other are required to have fire-rated exterior walls to prevent fire and smoke from passing between them (705; Table 602). Walkways and tunnels connect and penetrate these rated exterior walls compromising protection and potentially allowing heat and smoke to pass from one building to another.

#### **Code Requirements**

Section 3104 details specific requirements to ensure building occupant safety. These requirements are based upon the following fundamental principles:

**Principle #1** – Connected buildings shall be considered to be separate structures (3104.2). Unless the buildings are all on the same lot or exempt under specific accessibility requirements each building will be considered as a separate building when determining fire resistance, exterior wall ratings and egress.

**Principle #2** – The pedestrian walkway shall be of noncombustible construction (3104.3). Unless each building being connected is of combustible construction the connecting element must be noncombustible to minimize the travel of heat and smoke.

**Principle #3** – Once the rated exterior walls have been penetrated to accommodate a noncombustible connecting walkway, the interior of each building must be further protected with fire barriers of not less than 2-hour rated construction (3104.5). In order to avoid this requirement the following criteria must be met:

Exception #1 – The distance between the connected buildings is more than 10 feet ... the wall is constructed of a tempered, wired or laminated glass wall and doors subject to the following:

1.1. The glass protected with sprinklers in order to wet the entire surface of the interior glass.

1.2. Glass must be manufactured and installed in gasketed frames to avoid breakage with deflection from extreme heat.

1.3. Obstructions shall not be installed between the sprinkler heads and the glass.

Exception #2 - The distance between the connected buildings is more than 10 feet and the sidewalls of the glass are at least 50% open.


Exception #3 – Buildings are on the same lot.

Exception #4 – Where buildings are required by Section 705 to be rated more than 2 hours the walkway must be equipped with an NFPA 13 sprinkler system.


#### **Design Solutions**

The alternatives to fire barrier separations as listed above are very costly. Complying with the 2-hour separation requirement in Section 3104.5 is the least expensive option. A listed and labeled wide span McKeon assembly will easily protect any size opening. In the following three case studies, McKeon Door Company showcases three distinctly different technologies to resolve the same code application problem. The diverse design requirements between the three applications was not a challenge for McKeon, simply routine applications of standard products.

Case Study 1: Vertical Coiling with Complying Swing Egress Door(s)









#### EXIT ACCESS SEPARATION

• Case Study 2: Side Acting Accordion with Power-assisted Egress










#### • Case Study 3: Side Coiling without Egress



#### **Inquiry Discussion and Questions**

Pedestrian walkways can be located overhead connecting two or more buildings or underground as tunnels connecting two or more buildings. This connecting construction is viewed as a definite threat to life safety. The code attempts to build in safety measures that are intended as substitutes for complete and optimum separation. These substitutes include extensive active wet sprinkler systems, open side walls, and tempered and/or wire glass components. It would certainly make more sense to use the "real thing" by easily providing rated barriers with wide-span opening protectives at each end eliminating any threat of fire and smoke entering the walkways.

The following questions may be helpful:

- Have you been able to run a cost comparison separating the building from the walkway as opposed to protecting the walkway?
- Even though a pedestrian walkway will most likely be constructed of noncombustible materials, would you like to avoid the cost of sprinklers, limiting interior design and costly tempered and/or wired glass components?

Notes:

# **Vertical Opening Separation**

- Fundamental Guidelines
- Non-Egress Stairs
- Shaft Enclosure Escalator
- Vertical Exit Enclosures
- Atriums

Vertical Compartmentation



# **Fundamental Guidelines**

Sections 708, 1016, 1021 & 1022

Vertical openings between floors are designed consistently in multi-story buildings in many different shapes, heights and uses. For the purposes of code enforcement the following general categories are described in the building code:

- 1. Shaft Enclosures (708)
  - a. Escalators (708.2, Exception #2)
  - b. Mezzanines (708.2, Exception #9)
  - c. Stairs or ramps (708, 1020)
  - d. Elevators & dumbwaiters (708.14)
- 2. Atriums (404)
- 3. Vertical Exit Enclosures (Section 1022)
- 4. Non-egress and/or communicating stairs (708.2, Exception #11 & 1016.1, Exception #3 & #4)

Usually anytime two or more floors are open to each other a vertical opening is created and the phrase "floors are common with each other" is used to characterize the condition.

Two tightly interwoven fundamental principles drive the requirements of vertical opening protection. First, the migration of smoke, heat and toxic gases floor to floor. Second, egress of building occupants from upper levels to a safe level of exit discharge.

The case studies in this section illustrate the balance between these two principles in the enforcement of fire & life safety provisions for building occupants in multi-story buildings.

# **Non-Egress Stairs**

Sections 708.2; 1016.1; 1021.1; 1022.1

These case studies deal with a condition wherein several floors are common to each other. The floors are inter-connected with a non-egress communicating stair. Non-egress means – the communicating/convenience stair may not be considered as a required means of egress from any space.

### Fire & Life Safety Concerns

Multiple floors open to each other is perhaps one of the most vulnerable conditions to fire danger threats in any multi-story building. Fire suppression is concerned with confining a fire to the floor of origin and preventing the fire, or the products of the fire (smoke, heat and hot/toxic gases) from spreading to other levels. For building occupants, these conditions are not conducive to defend inplace strategies – rather to egress quickly from harm's way. Therefore, these requirements expressly demonstrate the overlap between passive, active and egress fire & life safety provisions.

#### **Code Requirements**


- An exit enclosure is not required in a stairway, in other than H and I occupancies, as long as the following conditions are met. The first requirement must be in place, the stairway serves an occupant load of less than 10 occupants, before either of the two following exceptions apply:
  - The stairway is open to not more than one story above its level of exit discharge, or
  - The stairway is open to not more than one story below its level of exit discharge. (1022.1)
- 2. A shaft enclosure is not required for floor openings created by unenclosed stairs or ramps when the following conditions are met: (708.2)
  - In other than occupancy groups H and I connect a maximum of two stories
     ... the two interconnected stories shall be provided with at least two means
     of egress. Such interconnected stories shall not be open to other stories.
     (1016.1, Exception #3)
  - In other than occupancy groups H and I the first and second floor stories above grade plane can be common as long as there are two means of egress from each floor, the interconnected stories are not open to other stories and the building is sprinklered throughout. (1016.1, Exception #4)

Note: In both cases mentioned above travel distance requirements must be met. The unenclosed stairs must be calculated into the travel distance. Neither case allows the unenclosed stairs to be a required exit. Therefore, the two required exits from each floor must be separate from the unenclosed stairs.

### **Design Solutions**


Since each space contains a stair the code will allow two floors common. In the following case studies, McKeon Door Company offers different products for very diverse design needs, yet there is not a compromise in fire & life safety.

Case Study 1: Vertical Coiling with Complying Swing Egress Door(s)












 Case Study 2: Vertical Coiling without Egress & Vertical Acting with Complying Swing Egress Door(s)

In the second case study sustaining an open design presented significant challenges to the design professional due to excessive heights which brought new meaning to the term wide-span openings. Without hesitation McKeon offered a unique resolve with a patented and time-tested product designed specifically for these seemingly difficult openings. With the vertical acting assembly, full height conforming rated egress doors were easily accommodated near the floor level while routinely fitting a super-sized height condition with rated vertical rolling steel.






Case Study 3: Side Acting Accordion with Power-assisted Egress







Case Study 4: Vertical Coiling without Egress



# **Inquiry Discussion & Questions**

This application, at first glance, would seem to fall under the atrium provisions because there are at least two floors common to each other. Notwithstanding the third floor is separated from the other two, the definition of an atrium is two or more floors interconnected. The purpose for separating the third floor from the first two floors is to consider the space under the shaft provisions in lieu of the atrium provisions. Within the shaft provisions, Section 708.2 Exception #11. This exception explains that a shaft enclosure is not required for floor openings created by unenclosed stairs or ramps in accordance with Exception #3 or #4 in Section 1016.1.

Section 1016 discusses travel distance, however, once the travel distance requirements are met Exception #3 will allow two connected stories to be common as long as the two floors include the following:

- · Stairs or ramps that are not used in the primary means of egress
- · The two connected stories shall be provided with at least two means of egress
- · The two connected stories shall not be open to other stories

Exception #4 will allow the first and second stories above grade plane to be connected as long as the following conditions are met:

- · Stairs or ramps that are not used in the primary means of egress
- The building is fully sprinklered
- The first and second stories above grade plane shall be provided with at least two means of egress
- The two connected stories shall not be open to other stories

Additionally, under the topic of number of exits and continuity, Section 1021.1, Exception #3 states: Exit access stairways and ramps that comply with Exception 3 or 4 of Section 1016.1 shall be permitted to provide the minimum number of approved independent exits required by Table 1021.1 on each story.

This language has been somewhat controversial and interpreted differently in local jurisdictions.

The following questions may be helpful:

- Do you have clients who wish to occupy multiple floors with a vertical common area connecting all floors?
- Can I show you how interconnecting unenclosed stairs can be incorporated into the design without creating shaft enclosures or complying with atrium provisions?
- Have you been concerned attempting vertical space separation avoiding the closed-in shaft appearance?
- Did you know there is technology available to offer you a wide-span opening protective to separate vertical spaces that can also serve as the required exit from unenclosed stairways?

# Shaft Enclosures – Escalator

Section 708.2, Exception #2, Items 2.1 and 2.2

An escalator provides convenient movement for building occupants communicating multiple floors. However, escalators are typically not a part of the required means of egress.

### Fire & Life Safety Concerns

Openings through floors allow fire – or the products of fire (smoke, heat and hot toxic gases) – to spread to other floors. Enclosing these spaces in rated shaft enclosures is certainly the most proficient method of mitigating fire and smoke migration between floors. However, the code incorporates optional provisions as exceptions to the completely sealed vertical shaft.

# **Code Requirements**

The following exceptions are allowed in lieu of creating a shaft:


Escalators must be enclosed unless the design incorporates the following requirements: (708.2, Exception #2, Subset 2.1 & 2.2)

First, an automatic sprinkler system must be installed throughout the entire building and, secondly an escalator must NOT be a portion of the means of egress system. If both of these issues are satisfied then the following criteria must be met:

- 1. The area of the floor opening between stories does not exceed twice the horizontal area of the escalator or stairway. (708.2, Exception #2, Subset 2.1)
- 2. The opening is protected by a draft curtain and closely spaced sprinklers in accordance with NFPA 13. (708.2, Exception #2, Subset 2.1)
- 3. In other than Groups B and M, this application is limited to openings that do not connect more than four stories. (708.2, Exception #2, Subset 2.1)


# **Design Solution**

#### • Case Study: Horizontal (Floor) Shutter



This case study features a much reduced aesthetically valuable ambiance with the design of a parking garage. However, from a fire & life safety perspective the need for fire and smoke protection is the same. The use of the 2-hour rated horizontal shutter quickly satisfies the basic requirement of opening protection at the opening and the escalator is enclosed.





### **Inquiry Discussion & Questions**

Escalators, whether in high-profile locations or low-profile parking garages, cannot be limited to the design criteria as stated above and maintain the desired ambiance of the space.

The following questions may be helpful:

- · Would you like to use the escalator as a required exit?
- Have you considered the cost difference between a shaft enclosure and the open escalator design requirements?
- Have you considered wide-span opening protectives as an alternative to conventional swing doors in shaft enclosure walls?

Notes:

# (Vertical) Exit Enclosures

Section 1022

Exit enclosures extend vertically through the interior of multi-story buildings in order to ensure timely and safe evacuation of occupants during an emergency. These enclosures include exit stairs and exit ramps.

#### Fire & Life Safety Concerns


Because exit enclosures penetrate horizontal floor and ceiling assemblies, fire, heat, smoke and toxic gases can potentially penetrate into building spaces at each floor level. Therefore, enclosures become critical barriers of protection for building occupants. The protected enclosure will be a non-contaminated exit path for at least one hour in buildings less than four stories and two hours in buildings four stories or more.

#### **Code Requirements**

- 1. Interior exit stairways shall be enclosed with fire barriers in accordance with Section 706. (1022.1)
- 2. Exit enclosures in buildings connecting four stories or more shall be rated at 2 hours; less than four stories at 1 hour. (1022.1)
- 3. Openings and penetrations shall be rated in accordance with Section 715. (1022.3)

#### **Design Solutions**


• **Case Study 1:** Side Coiling with Complying Swing Egress Door(s)



An absence of stacking space necessitated a unique McKeon product to seal this exit enclosure. The side coiling assembly requires a small box-like space and projects its 3-hour steel curtain with a conventional egress door along a very narrow pocket entry point and header slot path. However, when closed, complete compliance with shaft enclosure opening protective requirements is quickly achieved.







#### Case Study 2: Vertical Coiling without Egress

With a complying swing door hidden behind the columns, this expansive 3-hour rated roll-down assembly was more than enough protection to allow a wide-span open view only to close in case of fire.




GLASS VIEW TO EXTERIOR

• **Case Study 3:** Vertical Coiling with Complying Swing Egress Door(s)

Shaft enclosures that protect a required means of egress are extremely critical to the life safety of building occupants. From a design perspective it is often challenging to incorporate opening protectives in hi-profile tight spaces. It is equally difficult to satisfy egress requirements without compromising open spacious design. This vertical coiling and egress conforming assembly accommodates narrow header lines, obscure side guides and deploys with both separation and egress.





### **Inquiry Discussion & Questions**

Required exit stairs in vertical shaft enclosures ensure building occupant safe evacuation. Historically the designs of openings at the exit discharge level have been limited to conventional side-hinged swinging doors. The acceptance of the McKeon products as both wide-span opening protectives as well as a complying egress doors provide the designer flexibility without compromising code compliance.

The following questions may be helpful:

- Do you find building owners and maintenance groups struggling with door swing and maintenance on door hardware in high-traffic spaces?
- Do you seek an open and spacious appearance at the landing area of vertical stair enclosures?
- Would you like to use a required vertical exit stair shaft as an aesthetically pleasing communicating stair by opening the enclosure area at each floor?


Notes:

# Atriums

Section 404

An atrium is a floor opening, or a series of floor openings, that connects the environment of adjacent stories. By code definition an atrium is a space within a building that extends vertically and connects two or more stories. Atriums are designed to provide open and spacious vertical areas common with other building elements.

#### Fire & Life Safety Concerns

Unprotected vertical openings are often cited as the factor responsible for fire spread in incidents involving fire fatalities and/or extensive property damage. Section 404 addresses the need for protection of these specific building features in lieu of providing a complete floor and/or vertical shaft separation. In simple terms, the atrium provisions are extremely restrictive because these provisions are a substitute for a shaft enclosure.

#### **Code Requirements**

Vertical common areas that comprise an atrium are not considered un-protected, rather the atrium is considered a protected space by means other than a shaft enclosure. Listed below are the specific provisions allowing atriums to be open and spacious:


- The atrium floor area is permitted to be used only for low-hazard uses unless the individual space is provided with an automatic sprinkler system. (Section 404.2)
- An approved automatic sprinkler system shall be installed throughout the entire building. (Section 404.3)
- A fire alarm system shall be provided. (Section 404.4)
- Engineered smoke control system this system shall be installed in accordance with Section 909 when the atrium space exceeds more than two floors. (Section 404.5)
- Atrium spaces shall be separated from adjacent spaces by 1-hour fire barrier construction unless at least one of the following exceptions are met: (Section 404.6)
- A glass wall forming a smoke partition where automatic sprinklers are spaced 6 feet or less along both sides of the separation wall, or on the room side only if there is not a walkway on the atrium side, and between 4 inches and 12 inches away from the glass ... the entire glass surface must be wet upon activation ... the glass shall be mounted in a gasketed frame ...

- Provide a glass block wall assembly in accordance with Section 2110 ...
- The adjacent spaces of any three floors of the atrium shall not be required to be separated from the atrium ... if included in the smoke control calcs.
- Smoke control equipment must be on a standby power system. (Section 404.7)
- The atrium interior finish of walls and ceilings must be not less than Class B. (404.8)
- With the exception of the lowest level of the atrium, the required means of egress in the exit access system travel distance shall not exceed 200 feet.

# **Design Solutions**

The optimum protection of a vertical opening is to create a shaft enclosure. All of the requirements listed above that become a substitute for a shaft enclosure are erased from the design if a shaft is created. The cost savings can be tremendous.


#### • Case Study 1: Side Acting with Complying Swing Egress Door(s)




This unique case study features another of the McKeon diversified products for resolving multiple design/code challenges simultaneously. The lower floor travel path is a required design feature for egress and – combined with the non-rated second floor overlook – is certainly an ingenious solution. However, without the side acting, extreme height & egress conforming McKeon assembly this would not be possible!








### • Case Study 2: Horizontal (Floor) Shutter



In this case study the atrium space is essentially converted to a vertical compartment separation using the McKeon horizontal shutter. Please refer to the "vertical compartmentation" case studies at the end of this section for more information. Please note the absence of any smoke evacuation systems!








#### AREA SEPARATION

#### Case Study 3: Side Coiling without Egress




Even though this design incorporates an escalator, Item #2.1 under Exception #2 can only be applied if the area of the floor opening between stories does not exceed twice the horizontal projected area of the escalator. Since the area in this vertical open space is greater, the next option is to explore the possibility of creating a vertical shaft enclosure allowing no more than two floors common or interconnecting. With a 2.5" head-track design, 3-hour fire listing and unlimited width capacity, McKeon easily solved the problem with a triple curve, non-floor track 140' bi-part opening protective.











### **Inquiry Discussion & Questions**

The following questions may be helpful:

- The size of the smoke evacuation system is based upon the calculation of total cubic footage of not only the atrium space but all spaces that open into the atrium space. Can I help you minimize this system cost by reducing the cubic footage with wide-span opening protectives at critical locations in the atrium?
- Have you considered the cost savings if eliminating all of the atrium requirements by creating a fully enclosed shaft or horizontal compartmentation in this vertical space?

Notes:

# **Vertical Compartmentation**

Combined Code Principles from Chapters 4, 7 & 10

Protecting openings that connect multiple floors are currently addressed by the building and fire codes by way of vertical type shaft enclosures, atrium provisions or requirements relative to small floor or roof hatch type openings. In the following case studies a new technology and product application will be discussed wherein vertical compartments can be created separating any number of stories from each other. This will be accomplished by coordinating in one application the intent of the provisions found in both atrium and shaft enclosure requirements.

#### Fire & Life Safety Concerns

As stated in the previous case studies, vertical spaces that are interconnected and common with each other allow heat, smoke, and hot/toxic gases to migrate throughout an entire structure.

### **Code Requirements**

	,	

Figure 1



Within the current guidelines set forth in Section 708, regardless of which exception is applied, the basic core and shell of this structure is still going to be a protected shaft. For example, when one uses certain provisions of Section 404, by way of exception two floors can be common and the smoke evacuation can be eliminated from those two floors, yet all the other vertical separation provisions are retained. If there is a communicating stair placed in the atrium space, two floors are allowed to be common, under certain conditions, yet only two.

Figure 2

The question is, is it possible to eliminate the "vertical" open condition "horizontally" by extending the floor as shown in **Figure 2**, and if so how many floors can


Currently the code inherently prefers to treat these conditions as shafts and create sealed enclosures to prevent harmful migration. Within the shaft enclosure provisions (Section 708) there are 16 exceptions to the shaft enclosure rules. Included within these exceptions are the items discussed in the previous case studies ranging from non-egress stair to atrium allowances. However, none of these accepted methods specifically address the exclusive use of horizontal shutters to eliminate a vertical condition. **Figure 1**, shown at the left, addresses a vertical opening condition using the current conventional shaft enclosure requirements to seal the space. Note, the atrium requirements are designed to essentially replicate this condition.


be common? Exact code language is not found, however whatever the intent, if there is not a vertical opening, has the potential for migration of smoke, heat and hot/toxic gases been mitigated?

# **Design Solutions**


The following case studies demonstrate various accepted uses of the vertical compartmentation concept.

• Case Study 1: Horizontal (Floor) Shutter






#### • Case Study 2: Horizontal (Floor) Shutter








#### • Case Study 3: Horizontal (Floor) Shutter











• Case Study 4: Horizontal (Floor) Shutter





# **Occupancy Separation**





# **Fundamental Guidelines**

Table 508.4

Most buildings are designed for multiple uses that will typically result in more than one occupancy classification. The code provides three basic options for mixed occupancies in Section 508:

- 1. Accessory occupancies: Section 508.2
- 2. Separated occupancies: Section 508.2.4
- 3. Non-separated occupancies: Section 508.3

Chapter 3 of the building code specifically classifies a building according to its use and occupancy. The level of fire hazard varies with specific uses and occupancies in a building. However, this level of hazard and its potential affect on the building occupants is determined not only by the use and occupancy classification by construction type, height and area size, but also the use of passive and active fire protection systems. Chapter 5 combines fire-resistance levels, construction types and occupancy types to determine size and height limitations as well as separation requirements.

Increased fire resistance of the structural members of the building along with increased active and passive fire protection systems permits greater height and area allowances. Notwithstanding, the use and occupancy of the structure will become a determining factor regarding the extent of separation and compartmentation required. For example, a "B" (business occupancy) is allowed occupant load floor area to be calculated at 100 gross sq. ft. per occupant. However, a group "I-2" occupancy (hospital) which is a similar occupant load as far as quantity of people, is required to be calculated at 240 gross sq. ft. per occupant, more than double that of a "B" occupancy. The difference between these requirements is the use of the facility. Occupants in a hospital need better protection for a greater amount of time because they are non-ambulatory and most are dependent upon others for mobility or even life support. Therefore, the fire and life safety requirements designed to help protect building occupants are very different for each of these occupancies.

When buildings are designed as mixed occupancies there is a concern because basic fire and life safety requirements are being mixed within the same structure. Three basic options to eliminate confusion and ensure building occupant safety are outlined as follows:

#### **Accessory Occupancy:**

- 1. Accessory occupancies are those which are different from the main occupancy but ancillary to or a portion thereof. (508.2)
- 2. Aggregate accessory occupancies shall not occupy more than 10% of the area of the story. (508.2.1)
- 3. Aggregate accessory occupancies shall not exceed the tabular values in Table 503 without height and area increases. *(508.2.1)*
- 4. Accessory occupancies shall be individually classified in accordance with Section 302.1. (508.2.2)

#### Non-Separated Use:

To consider spaces under the Non-Separated Use requirements, the following must be met allowing NO separation between occupancies:

- 1. Each occupancy use shall be individually classified. (508.3.1)
- 2. Code requirements shall apply to each portion of the building based upon the occupancy classification of the space under consideration. (508.3.1)
- The most restrictive applicable provisions of Section 403 and Chapter 9 shall apply to the building or portion thereof in which the non-separated occupancies are located.
- 4. The allowable building area and height of the building or portion thereof shall be based on the most restrictive allowances for the occupancy groups under consideration for the type of construction of the building in accordance with Section 503.1. (508.3.2)

#### **Separated Use:**

The following requirements under the provisions of Separated Occupancies will bring these spaces into compliance without compromising design if separated with fire barrier walls according to Table 508.4:

- 1. Separated occupancies shall be classified in accordance with Section 302.1. (508.4.1)
- 2. Each separated space shall comply with the code based upon the occupancy classification of that portion of the building.
- 3. In each story, the building area shall be such that the sum of the ratios of the actual building area of each separated occupancy divided by the allowable building area of each separated occupancy shall not exceed 1. (508.4.2)
- 4. Each separated occupancy shall comply with the building height limitations based on the type of construction of the building in accordance with Section 503.1. *(508.4.3)*

# Mixed Occupancy – Accessory Use

Section 508.2

K-12 Schools are typically classified as "E" occupancies and usually incorporate mixed occupancies that are often considered accessory; business offices (B), full service kitchens (B), assembly areas (A), and K-12 (E) occupancies. Even though these spaces are ancillary to and a functional portion of the original larger occupancy they must be separated when they exceed the 10% rule.

#### **Fire and Life Safety Concerns**


In this case study we will examine the potential fire and life safety threats posed due to the use of open flames, combustible gases and solids, and exhaust hood extinguishing systems. These kitchens (B) are often common with assembly areas (A) in the facility potentially exposing large groups of building occupants to the associated hazards. In these cases and similar situations, where the spaces are greater than 10%, separation is required. Note: Since Table 508.4 does not require separation between an "A" and "E" occupancy, but does between these two and a "B" occupancy, the 10% determination can be an aggregate of the "A" and "E" when calculated against the "B" occupancy or kitchen portion.

# **Code Requirements**

Table 508.4 in Chapter 5 provides the requirements for separation of occupancy types. Should an accessory occupancy exceed the 10% rule, this table becomes the determining factor. Since the separation must be a fire barrier wall (508.4.4.1), Table 508.4 requires a 1-hour separation between an "A" and "B" occupancy or "E" and "B" occupancy when the building is fully sprinklered and 2-hour in non-sprinklered buildings.


#### **Design Solutions**

Case Study 1: Side Acting Accordion with Power-assisted Egress




This first case study examines the use of the McKeon Side Acting Accordion fire door for use only in case of fire. Otherwise, the assembly is hidden from view unless there is a fire and is activated by the smoke detector. Egress is accomplished by compliance to 1008.1.4.3.

### OCCUPANCY SEPARATION



#### • Case Study 2: Side Coiling without Egress




This case study is very similar to the previous application with the exception of an egress requirement. The McKeon side coiler without egress became the most economical solution without compromising life safety.






#### **OCCUPANCY SEPARATION**

Case Study 3: Side Acting with Complying Swing Egress Door(s)



This third case study features a different product under the same code premise, the requirement to separate an "A-3" occupancy (library) from the rest of the "B" occupancy, school (high school). The feature product is the Side Acting with Conventional Egress Assembly due to limited width of pocket space.





#### **Inquiry Discussion and Questions**

The purpose of this case study is to examine a somewhat questionable issue in the IBC. Most state jurisdictions with responsibility for schools have historically considered full-service kitchens to be accessory use spaces under the assumption that kitchens are occupancy type "A" (assembly) areas. And, since Table 508.4 does not require separation between an "A" and "E" occupancy, at first glance it would appear there is no need.

However, building officials from all areas of the country have expressed concern and suggest that a full-service kitchen in a school would be classified as a "B" occupancy and should therefore be separated from the structure as indicated in Table 508.4.

The following questions may be helpful:

- What is the classification of a full-service kitchen within an occupancy type "E" structure?
- Do you perceive a full-service kitchen that requires a type 1 exhaust hood extinguishing system as per the International Fire Code (IFC, Section 610.2 & IBC 904.2.1) a potential threat to the students?
- When you are required to separate the kitchen from the rest of the space are you concerned about easy access and traffic flow in front of the serving area?
- Would it be more convenient for your client to have the wide-span opening protective located in front of the serving area, separating the kitchen space, to also act as a security door when the kitchen is not in use?

Notes:

# Mixed Occupancy Use – Non-Separated vs Separated

Section 508; Table 508.4

Complying with Table 508.4 and providing fire barrier walls to separate occupancies can be limiting to the design. Also, using non-separated provisions to eliminate restrictive fire barrier walls becomes extremely costly due to added fire and life safety requirements that affect the entire structure.

#### Fire & Life Safety Concerns

Building structures are classified based on their occupancy and use. The purpose for classifying structures is to configure optimum safety requirements commensurate to the need as dictated by each individual use. These areas of concern are general building limitations, means of egress, fire protection systems and interior finishes. The challenge comes when buildings contain rooms or spaces that are different than the original building occupancy classification thereby creating a mixed use or mixed occupancy structure.

#### **Code Requirements**

In this case study the Conference/Training room is 1,188 square feet with an occupant load of 79. It is classified as an A-3 occupancy located in a 5-story Group B office building of Type IIIA construction. The conference room is classified as an A-3 because it is used for gathering a large number of people for assembly purposes (Section 303.1). It cannot be considered an accessory space because it exceeds both occupant load and area square footage of the accessory use exceptions.

First, let's look at the requirements imposed if we attempt to eliminate all separations as indicated in Table 508.4, in other words non-separated use.

#### Non-Separated Use:

- 1. Each use shall be individually classified. (508.3.1)
  - The entire building is classified as a "B" occupancy. The space under consideration (Conference/Training room) is an A-3 occupancy.
- 2. Code requirements shall apply to each portion of the building based upon
  - The requirement referred to are those involving egress, travel distance, occupant load driven issues, etc. (508.3.1)

- 3. The most restrictive applicable provisions of Section 403 and Chapter 9 shall apply to the entire building or portion thereof. *(508.3.1)* 
  - Section 403 encompasses the requirements for hi-rise construction and Chapter 9 include the provisions for fire protection systems. In other words, the building will have to incorporate the most protective and restrictive requirements of these chapters. For example:
    - Standpipe system (905)
    - Smoke detection (403.4.1)
    - Fire Alarm systems (403.4.2)
    - Emergency voice/alarm communication system (403.4.3)
    - Fire command (403.4.4)
    - Smoke removal (403.4.6)
    - Standby power (403.4.7)
    - Emergency power systems (403.4.8)
- 4. The allowable height and area of the building or portion thereof shall be based on the MOST RESTRICTIVE allowances for the occupancy group under consideration for the types of construction of the building in accordance with Section 503.1. (508.3.2)
  - The height and area allowances for this requirement would not allow the building to be five stories. Most likely only three at best.


# **Design Solutions**

#### Case Study 1: Vertical Coiling with Complying Swing Egress Door(s)


|--|--|--|--|

In this case study the most equitable alternative would be to provide occupancy separation at the conference/training room area separating the A-3 from the B occupancy. By incorporating a wide-span opening protective the design is not limited to a pair of conventional swing doors for opening width. Further, the overall building design can accommodate 5 stories and remain a Type IIIA building eliminating the need for imposing all of the most restrictive provisions of Section 403 and Chapter 9.







• Case Study 2: Side Acting with Complying Swing Egress Door(s)



This case study is a text book case of occupancy separation, but is very unique in product application problem solving from an architectural perspective. The fire barrier wall was traversed the structure in very limited space areas. Pocket space was limited in width not depth and headroom was extremely limited. Due to the ambiance of the space conventional swing doors on magnetic hold-opens was not an option. McKeon provided the S7000 series which requires no more than 3.5" of pocket width and less than 3" of head track width space. Due to a patented side acting technology the assembly easily incorporated four conventional swing doors and simply allowed the entire assembly to slide into a 3.5" space parallel the fire barrier wall. Upon command of the smoke detector the 3 hour assembly slides into place providing occupancy separation and conforming egress.




 Case Study 3: Vertical Coiling with Complying Swing Egress Door(s) & Vertical Coiling without Egress



In this third case study McKeon Door Company offers a solution to a difficult challenge by providing two different products within the same space. A combination of six fire-rated vertical rolling shutters installed on a diagonal path of travel and one vertical coiling assembly with conventional egress for egress from the space. This solution preserves the beauty of the space without compromising mixed occupancy separation requirements.


8












#### **OCCUPANCY SEPARATION**

• **Case Study 4:** Vertical Acting with Complying Swing Egress Door(s)

0 0	
0	

This application illustrates McKeon's capacity to provide 3-hour separation, conforming to a large occupant load exit width without occupying side stacking space. Deploying only in case of fire or emergency, both egress and fire separation requirements are satisfied without compromising design.





### **Inquiry Discussion and Questions**

Fundamentally, separating the interior of buildings with fire barriers wherever occupancies change as required in Table 508.4 is simple and straightforward. However when designs promote mixed occupancies without separation, the code is left to create alternate means of protection to compensate for the loss of fixed barriers. Hence, in the absence of passive redundant systems, code enforcement becomes a tremendous challenge and the non-separated use provisions govern. These provisions are extremely costly.

The following questions may be helpful:

- Are you frustrated because open design is difficult when incorporating fire barrier walls as occupancy separations?
- Can I show you how wide-span opening protectives can eliminate the need to design non-separated structures?
- Have you considered the additional cost incurred by conforming to the nonseparated use requirements?
- Do you really want to impose the most restrictive requirements of Chapter
  4, Section 403 hi-rise provisions as well as the most restrictive requirements
  of Chapter 9 to the entire building?

#### Notes:

# **Area Separation**





## Allowable Area

Section 706; Table 503

The allowable height and area of a building structure is determined largely by two basic factors; first, the combustibility of its structural materials and second, occupancy type or use and purpose of the building. When a building design exceeds the established values, the intent of the code is to create another separate building structure to incorporate the increase. Since this is not always desirable, the code will allow interior fire walls to serve as separations sufficient to consider each space a separate structure within the tabular value allowance. In essence multiple compliant buildings can be created within the same structure and under a common roof.

## Fire & Life Safety Concerns

Building height and area is calculated to accommodate three fundamentals principles in fire & life safety. First, the structural elements may be rated or non-rated and are intended to maintain structural integrity during fire and other life threatening emergencies. This means the greater the protection of the structural elements, the larger the height and area. Second, additional height and area are allowed due to the use of active fire suppression systems such as sprinklers. And third, the implementation of passive redundant elements to compartmentalize the area and provide protection for building occupants as they egress the structure. Rated construction protects the structural elements, sprinklers protect the building contents, and egress allows building occupants protection by being removed from harm's way. All three principles overlap and work together to ensure a building occupant is afforded the time to exit the structure without harm. Therefore, the reduction or absence of any of the three elements can compromise the fire and life safety of building occupants and potentially destroy property.


Another concern is the size of openings allowed in the passive redundant system, particularly in fire walls that are crucial to the area limitations. Opening size limitations are imposed to maintain the integrity of the wall during fire conditions. Opening protectives inherently accommodate strict requirements to adequately protect and maintain the integrity of the openings. The structural integrity of the fire wall must be maintained regardless of the wall opening size or its opening protective. It is critical to remember; the opening protective protecting an opening in a fire wall is not required to conform to structural integrity provisions. The opening protective is protecting the opening - NOT the wall. A fire wall used for area separation is allowed openings and opening protectives, however, a fire wall used as a party wall cannot have openings.

## **Code Requirements**

- 1. Table 503 of Chapter 5 indicates the tabular height and area allowances for specific building construction types and occupancies.
- 2. Each portion of a building separated by one or more fire walls shall be considered a separate building. (706.1)
- Openings in fire walls are subject to the following criteria (706.8): *Non-sprinklered buildings* – Openings shall not exceed 156 square feet and the aggregate width of openings at any floor shall not exceed 25 percent of the length of the wall.


*Sprinklered buildings* – Openings shall not be limited to 156 square feet and the aggregate width of openings at any floor shall not exceed 25 percent of the length of the wall.

## **Design Solutions**






In this application McKeon resolved two significant design code compliance problems without sacrificing wide span open appearance. First, nearly the entire opening was necessary to meet the exit width requirements located in the primary means of egress system in an "A" occupancy. Using the McKeon accordion assembly would not comply because of a) the large distance to be covered and b) the length of time required to open wide enough to allow for immediate egress. Second, there was not sufficient stacking space for any of the McKeon side acting models. However, because headroom was plentiful and large occupant load egress was a necessity, the T5000 series incorporating six egress conventional swings doors, three doors set in each direction to accommodate dual egress, was the perfect fit and the only viable solution.




## AREA SEPARATION

 Case Study 2: Vertical Acting with Complying Swing Egress Door(s), Vertical Coiling without Egress & Side Acting without Egress


















## **Inquiry Discussion and Questions**

The decision to use the area separation strategy is determined early in the conceptual design phase of the project.

Resistance to incorporate fire walls may be due to the following:

- Limited understanding of the code allowances for considering one structure as multiple buildings.
- The structural integrity of the fire wall design appears costly and overwhelming compared to the basic design; i.e. parapets, return exterior walls, etc.
- Limited understanding of diverse wide-span opening protectives. Conventionally, openings in any wall seem to follow the swing door model, largely due to the perception that complying egress is limited to these kinds of doors and mullions. This traditional way of traversing throughout the building is very limiting and simply prohibitive to open design.

The following questions may be helpful:

- Have you ever been frustrate designing a structure because you exceeded the area allowances and were pushed to increase the construction type?
- When you are required to change a construction type to accommodate additional area, what is the increase in cost? How does your client feel about the increase?
- Are you hesitant to consider an area separation wall because of the limitations for openings as implied with conventional swing doors?

#### Notes:

# **Corridor Separation**

Corridor Separation – Healthcare



## **Corridor Separation – Healthcare**

Section 407.2.4

Gift shops focus on retail exposure to the public. Nonetheless they are located in hospitals and typically open to corridors that fall under strict provisions for life safety. Compliance with these strict provisions using conventional opening protectives can limit market exposure.

### Fire & Life Safety Concerns

The corridor system in a hospital is designed to protect non-ambulatory patients and their attendants from the transfer of heat and smoke from adjacent spaces. Gift shops offer a particular threat due to the potential fuel load created by large quantities of merchandise and paper goods. So it goes, the smaller the shop the lesser the threat of contents that are burning during a fire emergency. Therefore the code requires no separation at the corridor opening of a gift shop if the square footage in minimal.

#### **Code Requirements**


Gift shops are allowed to be open to the corridor where the total square footage of the space does not exceed 500 square feet. (407.2.4)

To better understand the opening protective requirements let's review the corridor provisions for I-2 occupancies (hospitals).

- 1. The corridor wall shall be constructed as a smoke partition. (407.3)
- 2. Smoke partitions are not required to be fire-rated. (710.3)
- Doors protecting openings in smoke partitions in I-2 occupancies are as follows:
  - Non-fire-rated. (407.3.1)
  - Not required to be self-closing or automatic-closing. (407.3.1)
  - Must be positive latching. (407.3.1)
  - Shall provide an effective barrier to limit the transfer of smoke. (407.3.1)
  - Must be a smoke and draft control door listed under UL1784. (710.5.2)

## **Design Solutions**


#### Case Study 1: Side Acting Accordion with Power-assisted Egress



Incorporating the McKeon wide-span side acting accordion allows this space to be open for business without view or customer access restriction. At the command of a smoke detector the large width opening is quickly protected and the fire & life safety corridor provisions are not compromised.








## **CORRIDOR SEPARATION**

• **Case Study 2:** Vertical Acting with Complying Swing Egress Door(s)

• •	• •	 •
	=1	
	= 0	
	<b>≓</b>  Ľ	_
	1 N 1	
	N.	
	100	

Incorporating the McKeon T5000 technology, the egress doors are completely concealed in the vertical space above, to close only in case of fire.






### **CORRIDOR SEPARATION**

#### • Case Study 3: Vertical Coiling without Egress

Egress is not required but a 2-hour fire rating is. This work station is left open during normal business hours and easily lowered and locked after hours. Completely automated, whether in fire or security mode any building occupant can operate the assembly.






• Case Study 4: Vertical Acting with Complying Swing Egress Door(s)

8	İ.	8	4	


The width of the opening did not allow for much more rated assembly than the doors themselves. Using the T5000 technology a full pair of swing doors, meeting the required exit width, are incorporated in an opening that does not afford space for accommodating the doors mounted in the surrounding construction. By taking advantage of progressive wide-span opening protective engineering, neither the space nor the code requirements are compromised.






## CORRIDOR SEPARATION

• **Case Study 5:** Side Acting Accordion with Complying Swing Egress Door



The accordion technology easily accommodates a conventional egress door.





## **Inquiry Discussion & Questions**

This gift shop space is considered an incidental use area when it exceeds 500 square feet. Most designs will limit this space to 500 square feet or incorporate sheet rock, swing doors and wire glass to accommodate greater area spaces that open to the corridor. Table 508.2 lists other incidental use areas but does not include gift shops in I-2. The issue that drives the gift shop separation requirement is that it opens to a corridor. Incidental use areas that are required to be separated as listed in Table 508.2 may or may not be open to a corridor, regardless, each must be separated. This understanding would open an interesting discussion when attempting to differentiate between corridor separation spaces and/or incidental use areas.

The following questions may be helpful in understanding pertinent challenges:

- · Do you desire to have a gift shop larger than 500 square feet?
- Even though a gift shop, larger than 500 square feet, is not shown on Table 508.2 as an incidental use space ... why is it required to be separated with 1-hour construction?
- May I show you how McKeon can help you eliminate a closed-in appearance at the corridor bordering gift shops exceeding 500 square feet in area?
- Is a waste and linen room required to be separated if it is not located on a corridor? (See Table 508.2)
- Which is the least expensive when separating laboratories or vocational shops; 1-hour separation with wide-span opening protectives or elaborate fire-extinguishing systems in addition to sprinklers? (See Table 508.2)

#### Notes:

# **Smoke Compartmentation**

- Smoke Compartments Healthcare
- Smoke Barriers Healthcare



## Smoke Compartments – Healthcare

Section 1014.2.2

The compartmentation requirements in these case studies are unique to hospital occupancies and are driven, for the most part, by means of egress provisions.

## Fire & Life Safety Concerns


The code allows patient rooms to be arranged in open suites. However, this type of arrangement supposes a low patient-to-staff ratio where the staff is directly responsible for the safety of the patients in the event of a fire. To ensure safety, small smoke compartments with short-distance egress to protected exits become critical.

## **Code Requirements**

- 1. Habitable rooms or suites in Group I-2 occupancies shall have an exit access door leading directly to a corridor. (1014.2.3.1)
- 2. Suites of patient sleeping rooms shall not exceed 5,000 square feet. (1014.2.4.1)
- 3. Suites of other than patient sleeping rooms shall not exceed 10,000 square feet. (1014.2.2)
- 4. Any patient sleeping room, or any suite that includes patient sleeping rooms, of more than 1,000 square feet shall have at least two exit access doors remotely located from each other. (1014.2.3.2)
- 5. Any room or suite of rooms other than patient sleeping rooms of more than 2,500 square feet shall have at least two access doors remotely located from each other. (1014.2.4.2)
- 6. Travel distance between any point and an exit access door in a room shall not exceed 50 feet. (1014.2.4.2)
- 7. Travel distance between any point in a suite of sleeping rooms shall not exceed 100 feet. (1014.2.3.3)
- 8. Vision panels are required in cross-corridor application of I-2 occupancies. (710.5, Exception #1)
- 9. Walls designed to create separate suites shall be construction as non-rated smoke partitions. (1014.2.7)
- 10. Openings within smoke compartment walls that are not used to protect a ver-

tical opening or an exit are not required to have a fire-rating but shall provide an effective barrier to limit the transfer of smoke. Also, these opening protectives do not have to be self-closing. *(Section 407.3)* 


## **Design Solutions**



#### Case Study 1: Side Acting with Complying Swing Egress Door(s)


In this case study we find it difficult to maintain continuity with compartmentation when passing through corridors or other open areas with smoke partition walls. With the wide-span capabilities of the McKeon door assembly there is no compromise with building function ability and code compliance.





### SMOKE COMPARTMENTATION


• Case Study 2: Side Acting Accordion with Complying Swing Egress Door



This side acting accordion offers conventional egress with a swing door attached to wide panels that provide a compact profile for less stack space.







## **Inquiry Discussion and Questions**

Often more desirable floor plans will be compromised to accommodate smoke compartmentation requirements. Rooms become smaller, corridors often inhibited with opening protectives, nurses stations altered, etc. to create life-saving smoke free spaces. Most often these adjustments become routine without an understanding of wide span opening protective technology.

The following questions may be helpful:

- May I show you how a smoke compartment separation can cross a corridor without compromising the space?
- Did you know that a side acting accordion door can be used in a means of egress across a corridor regardless of the occupant load served?
- Smoke compartments are no respecter of open spaces. Can I show you how you can span virtually any distance without compromising the space?



## Smoke Barriers – Healthcare

Section 710

Smoke barriers divide areas of a building into separate smoke compartments. These dividing walls allow building occupants time to be evacuated or relocated to other smoke compartments. In other words, smoke barriers separate portions of buildings into areas of refuge capable of resisting the passage of smoke and fire for 1 hour (Section 710.4).

#### Fire & Life Safety Concerns

Smoke barriers are specifically required in I-2 (hospital) occupancies due to the non-ambulatory status of the building occupants (Section 407.4). Usually these occupants require assistance and care when being evacuated or relocated during an emergency. There must be a protected area where these patients can be placed until safely evacuated from the building. Smoke barriers in Group I-2 occupancies provide this defend-in-place mechanism.

#### **Code Requirements**

The following five requirements designate the use of smoke barriers in Group I-2 occupancies:


- 1. Group I-2 occupancies are required to subdivide every story into smoke compartments with an area not more than 22,500 square feet. (407.4)
- 2. Smoke compartments are to be divided using smoke barrier walls in accordance with Section 710. (407.4)
- 3. Smoke barriers are required to subdivide every story used by patients for sleeping or treatment with an occupant load of 50 or more persons into at least two compartments. (407.4)
- 4. Travel distance in smoke compartments shall not exceed 200 feet. (407.4)
- Independent egress A means of egress shall be provided from each smoke compartment created by smoke barriers without having to return through the smoke compartment from which means of egress originated. (Section 407.4.2)

In order to accommodate an opening in a smoke barrier wall the following opening protective requirements must be met:

- 1. Minimum fire rating of 20 minutes. (Section 715.4.3 & Table 715.4)
- 2. Vision panels. (Section 710.5)


## **Design Solutions**

#### Case Study 1: Side Acting Accordion with Power-assisted Egress




In this case study the intent is to add to an existing I-2 occupancy a 9,700 square foot Critical Care Suite. The existing building construction type is IIIA with 21,324 square feet and the desire is to have the new suite as open as possible to the existing hospital corridor system. The placement of a smoke barrier wall at this new addition connection is a specific code requirement in order to fall within the 22,500 square foot limitation. With the use of the McKeon wide-span labeled assembly approved for egress, the opening protective requirements are met without compromising the spacious clear open ambiance desired.





Case Study 2: Vertical Coiling with Complying Swing Egress Door(s)




Smoke barrier requirements are no respecter of design. Regardless of the size of the space, these barriers must be maintained throughout the building. McKeon Door can easily meet the ambiance with these unusually large openings without compromising fire & life safety or egress.







 Case Study 3: Side Acting with Conventional Egress Door(s) & Vertical Acting with Complying Swing Egress Door(s)



These two very different technologies converge on the inside corner of the structure to complete the smoke barrier separation creating separate refuge area compartments. Operating as duel function assemblies they are also located to separate the corridors from additional spaces.







## **Inquiry Discussion & Questions**

In principle, smoke compartmentation and smoke barrier separation are the same with minor differences. Smoke barriers are created using 1-hour rated walls (Table 715.4) and the separations are incurred at a minimum of 22,500 square feet. Smoke compartments are created using non-rated smoke partitions and the separations are incurred at a minimum of 5,000 square feet in suites of sleeping rooms and 10,000 square feet in non-patient room areas. Smoke compartment applications occur in Group I-2 occupancies/hospitals and smoke barrier applications occur in Group I-2 and/or Group I-3 occupancies/prisons.

Helpful questions for smoke barrier applications can be found in the smoke compartmentation case study.

Notes:

# Appendix

- Definitions
- Resources



## Fire Walls – Section 706

#### Definition

A fire-resistance-rated wall having protected openings, which restricts the spread of fire and extends continuously from the foundation to or through the roof, with sufficient structural stability under fire conditions to allow collapse of construction on either side without collapse of the wall. *(702)* 

Fire Ratings: (Table 706.4)

2-hour

3-hour

4-hour

#### **Opening Protection:** (706.8)

*Non-sprinklered buildings* – Openings shall not exceed 156 square feet and the aggregate width of openings shall not exceed 25 percent of the length of the wall. *Sprinklered buildings* – Openings may exceed 156 square feet but the aggregate width of all openings shall not exceed 25 percent of the length of the wall.

#### **Design Notes**

- Each portion of a building separated by one or more fire walls shall be considered a separate building. (706.1)
- Where a fire wall separates occupancies that are required to be separated by a fire barrier wall, the most restrictive requirements of each separation shall apply. (706.1)
- Regardless of the rating of the opening protective, fire walls cannot have openings that exceed 25 percent of the length of the wall. (706.8)
- Fire walls constructed as party walls shall NOT have openings. (706.1.1)

- Exceeding area allowances (Table 503)
- Horizontal Exits (1025)
- Means of Egress, McKeon Model AC8800 Only (1008.1.2 Exception #6)

## Fire Barriers – Section 707

#### Definition

A fire-resistance-rated wall assembly of materials designed to restrict the spread of fire in which continuity is maintained. (702)

Fire Ratings: (Table 707.3.9)

1-hour

2-hour

3-hour

4-hour

#### **Opening Protection**

*Non-sprinklered Buildings* – Openings shall be limited to a maximum aggregate width of 25 percent of the length of the wall, and the maximum area of any single opening shall not exceed 156 square feet. (707.7)

Sprinklered Buildings – Openings may exceed 156 square feet but must be limited to a maximum aggregate width of 25 percent of the length of the wall, unless the opening protective assembly has been tested in accordance with ASTM E119 and has a minimum fire-resistance rating not less than the fire-resistance rating of the wall. (707.7 Exceptions #1 & #3)

#### **Design Notes**

 A fire barrier may have an opening exceed the 25 percent rule if the building is sprinklered and the opening protective assembly is tested under the provisions of ASTM E-119. As seen below, most fire-rated walls used in building design will fall under Section 707, Fire Barrier Walls.

- Shaft Enclosures (708.4)
- Exit Enclosures (1022.1)
- Exit Passageways (1023.1)
- Horizontal Exits (1025.1)
- Atriums (404.6)
- Incidental Use Areas (508.2)
- Control Areas (414.2.1)
- Separation of Mixed Occupancies (Table 508.4.4.1)
- Single-Occupancy Fire Areas (Table 707.3.9)

## Fire Partitions – Section 709

#### Definition

A vertical assembly of materials designed to restrict the spread of fire in which openings are protected. (702)

#### Fire Ratings (709.3)

1-hour

1/2-hour (709.3, Exceptions #1 & #2)

#### **Opening Protection**

Opening protectives in fire partitions shall have a minimum fire rating of 20 minutes and a maximum of 45 minutes (Table 715.4) and shall be smoke tested under UL 1784. (709.6)

#### **Design Notes**

- Most rated corridor walls fall into this category. (709.1 and Table 1018.1)
- Corridor walls in an I-2 Occupancy (Hospital) shall be constructed as Smoke Partitions. (407.3 & 711)

- Walls separating dwelling units in the same building (709.1)
- Walls separating sleeping units in occupancies in Group R-1 Hotel, R-2 and I-1 Occupancies (709.1)
- Walls separating tenant spaces in covered mall buildings as required by Section 420.2 (709.1)
- Corridor walls as required by Section 1018.1 (709.1)
- Elevator lobby separation as required by Section 708.14.1 (709.1)

## Smoke Barriers – Section 710

#### Definition

A continuous membrane, either vertical or horizontal, such as a wall, floor, or ceiling assembly that is designed and constructed to restrict the movement of smoke. (702)

#### Fire Ratings (710.3)

1-hour

#### **Opening Protection**

Opening protectives in smoke barriers shall have a minimum 20 minute fire rating and UL 1784 smoke tested. (*Table 715.4*)

#### **Design Notes**

- Door assemblies in cross-corridor smoke barriers of I-2 Occupancies (Hospitals) shall have vision panels. (710.5)
- Smoke barriers constructed of minimum 0.10-inch-thick steel in I-3 Occupancies (Jails & Prisons) are not required to be 1-hour rated. (710.3)

#### Applications

In *I-2 Occupancies* (Hospitals) smoke barriers are required to subdivide every story used by patients for sleeping or treatment. (407.4) As per the following:

- 50 or more persons / minimum 2 smoke compartments
- Each compartment cannot exceed 22,500 square feet
- Travel distance shall not exceed 200 feet to a smoke barrier door

In *I-3 Occupancies* (Jails & Prisons) smoke barriers are required to divide every story occupied by residents for sleeping. (408.6) As per the following:

- · 50 or more persons / minimum 2 smoke compartments
- Maximum number of residents in any smoke compartment is 200
- Travel distance to any exit access component shall not exceed 150 feet
- Travel distance to any smoke barrier door shall not exceed 200 feet

## Smoke Partitions – Section 711

#### Definition

A partition constructed to limit the transfer or passage of smoke. (711.4)

Fire Ratings (711.3)

Non-rated

#### **Opening Protection**

Door assemblies shall be UL 1784 tested and self closing by smoke detection. (711.5)

#### **Design Notes**

 Smoke partitions and their use lack clarity in the building code. Although it is not specifically referenced, smoke compartmentation can be accomplished with non-rated smoke partitions.

- Corridor walls of I-2 Occupancies (Hospitals) (407.3)
- Elevator Lobbies (708.14.1 Exception #5)
- Separation of Suites in Group I-2 Occupancies (1014.2.7)

## International Building Code, 2009

Means of Egress (AC8800 Series)

1008.1.2 Door Swing. Egress doors shall be side-hinged swinging.

#### **Exceptions:**

6. In other than Group H occupancies, horizontal sliding doors complying with Section 1008.1.3.3 are permitted in a means of egress.

**1008.1.4.3 Horizontal sliding doors.** In other than Group H occupancies, horizontal sliding doors permitted to be a component of a means of egress in accordance with Exception 6 to Section 1008.1.2 shall comply with all of the following criteria:

- 1. The doors shall be power operated and shall be capable of being operated manually in the event of power failure.
- 2. The door shall be openable by a simple method from both sides without special knowledge or effort.
- 3. The force required to operate the door shall not exceed 30 pounds (133 N) to set the door in motion and 15 pounds (67 N) to close the door or open it to the minimum required width.
- 4. The door shall be openable with a force not to exceed 15 pounds (67 N) when a force of 250 pounds (1100 N) is applied perpendicular to the door adjacent to the operating device.
- 5. The door assembly shall comply with the applicable fire protection rating and, where rated, shall be self-closing or automatic closing by smoke detection in accordance with NFPA 80 and shall comply with Section 715.
- 6. The door assembly shall have an integrated standby power supply.
- 7. The door assembly power supply shall be electrically supervised.
- 8. The door shall open to the minimum required width within 10 seconds after activation of the operating device.

## NFPA 101 Life Safety Code, 2009

Means of Egress

#### 7.2.1.4 Swing and Force to Open

**7.2.1.4.1.4b** Horizontal-sliding doors complying with 7.2.1.14 shall be permitted.

**7.2.1.14 Horizontal-Sliding Doors.** Horizontal-sliding doors shall be permitted in means of egress, provided that the following criteria are met:

- 1. The door is readily operable from either side without special knowledge or effort.
- 2. The force that, when applied to the operating device in the direction of egress, is required to operate the door is not more than 15 lbf (67 N).
- The force required to operate the door in the direction of door travel is not more than 30 lbf (133 N) to set the door in motion and is not more than 15 lbf (67 N) to close the door or open it to the minimum required width.
- 4. The door is operable using a force of not more than 50 lbf (222 N) when a force of 250 lbf (1100 N) is applied perpendicularly to the door adjacent to the operating device, unless the door is an existing horizontal-sliding exit access door serving an area with an occupant load of fewer than 50.
- 5. The door assembly complies with the fire protection rating, if required, and, where rated, is self-closing or automatic-closing by means of smoke detection in accordance with 7.2.1.8 and is installed in accordance with NFPA 80, Standard for Fire Doors and Fire Windows.

## **ICC Evaluation Service Report**

ESR-2219

For access to this report:

- · Download from the ICC Evaluation Service Website at www.icc-es.org
- Contact McKeon at info@mckeondoor.com
- Telephone at 800-266-9392

**NOTES & OBSERVATIONS** 

**NOTES & OBSERVATIONS** 



#### McKeon Door Company 44 Sawgrass Drive Bellport, NY 11713 Phone: 800-266-9392 Fax: 631-803-3030 Email: info@mckeondoor.com www.McKeonDoor.com

of TOHERS & WESTGATE

© McKeon Rolling Steel Door Co., Inc.